



PO Box 2628  
Valley Center CA 92082  
Tel: 760-855-1219  
Fax: 760-749-0842

Printed in U.S.A.

#### KORE END LINK INSTRUCTIONS

Please read all instructions from start to finish before beginning installation

#### Parts List:

<u>Description</u>	<u>Qty</u>
Rod End Male	2
Rod End Female	2
Jam Nut	2
Zinc-Plated End Link Yokes	2
½ x 3 inch Grade 8 bolts	4
½ inch top lock nuts	4
Stainless Steel Misalignment Spacers	8
5/8 Grade 8 SAE washer	2
5/8 Lock Nut	2

#### BE ADVISED:

- This suspension system is designed to give a smoother, more controlled ride over rough or unimproved surfaces. It will also give a more controlled, balanced ride over pavement. Whatever the conditions, KORE INC. suspension may permit you to attain speeds that are faster than an unmodified vehicle over the same terrain. KORE INC. suspension is so good that the driver may not even realize how fast he or she is driving, thereby exceeding the limitations of his or her skill. The user assumes all liability for this increase in speed. KORE INC. suggests a slow and gradual adaptation to the increased capabilities of the vehicle.
- Please remember that KORE INC. is only improving the suspension. Other drive train components remain the same. Although our suspension will allow fewer impacts to be transmitted to the chassis, we do not guaranty that your truck will remain intact if you abuse it beyond the protection our system inherently provides. You can still roll your truck or break it in half if you try hard enough or are simply not paying attention to what you are doing.
- KORE INC. suspension permits jumping the truck. Many have seen the photos. It takes a lot of skill to do


this without damaging or destroying your vehicle and/or being injured or killed. Please do not try to imitate these photos. It looks easy, but it's not, SO DON'T DO IT. If you attempt something like this you could find yourself way over your head and you probably won't recover. We are professionals with many years of experience. We have done our very best to provide you with the finest suspension money can buy. Please also be a professional and learn to use it carefully and responsibly. Remain within your personal limitations and the limitations of your vehicle.

- Before installing this suspension system, have your alignment checked. Make absolutely sure that your alignment falls within factory specifications. It has been our experience that some Dodge trucks, even new ones, cannot be aligned to OE specs. If your vehicle cannot be aligned to factory specifications, do not install this suspension system.
- Before installation, have a certified mechanic carefully check your vehicle for any signs of damage or severe, structural corrosion. If your truck exhibits any structural weakness whatsoever, do not install this system.
- Compare the parts you have against the parts in the list. If any parts are missing or damaged, please call 760-855-1219. KORE will take care of it immediately. Do not attempt to substitute any part or fastener with anything from any other source but KORE INC.
- During assembly use blue (medium strength) thread locking compound on every nut and bolt, both OE and KORE.
- Never use an impact wrench on any component. Always use a torque wrench. If it's a factory part you must remove and reinstall, then put blue thread locking compound on it and torque it to the factory specifications. If it's a KORE INC. part, then put blue thread locking compound on it and torque it to our specifications. Don't try to guess. Use the correct tools, take your time and do the job right. These are high-quality parts that will last a long time if you install them correctly.
- Do not plate, chrome, anodize, polish or otherwise change the finish or surface of any KORE INC. part. You may weaken the structure. Call us if you want something special done to your parts. We'll either do it for you or point you in the right direction.
- Do not alter any parts in our system. Do not add anything to what we offer. Do not fabricate anything you think will work better. Do not mix any factory or after-market parts with our system. If you do any of the aforementioned things, KORE INC. will take no responsibility for your system and your warranty will be immediately voided. If you have an idea concerning a future modification of your KORE INC. system, just call us first. We will be glad to discuss the consequences and the correct use of our product from an engineering standpoint.
- KORE INC. developed this system to use no larger than 37 x 12.50 tires on wheels with the OE backspace and offset. This tire size will not fit without body modifications. A 35 x 12.50 tire on the OE wheel should work without any body trimming or modifications – as long as it is used with a wheel of OE backspace and offset. We say "should work" because your truck may differ due to production variances or consumer modifications such as nonstandard control arms. Please note that the OE wheel on the 2003 Dodge Ram has a very large 6.25" backspace and a positive 40mm offset. This is a very deep set wheel. Most wheel sizes currently offered will not work correctly.
- In general, oversize tire and wheel combinations may increase stress and wear on steering components leading to increased maintenance and greater risk of component failure, including loss of steering control. Property damage or personal injury may result. Large tire and wheel combinations may also alter speedometer calibration, reduce braking effectiveness and alter vehicle center of gravity. KORE INC. suggests you choose your tire and wheel combination very carefully in order to ensure full suspension articulation without interference with suspension or body components.
- For trucks carrying loads under 1000 lbs we recommend cold pressures of 40 psi in front and 30 in the

rear. Due to their thick sidewall construction, heavy duty off-road tires such as the “Goodyear Wrangler MTR” or the “Toyo Mud Terrain” may require even less pressure to provide the best performance. Try to experiment to find the tire pressures that work best for you. If you are running pressures above 40 psi to attain longer tire life or better gas mileage, please be aware that your suspension will not function optimally. Higher tire pressures may only increase tire life and gas mileage by 1-2%. Lowering your tire pressures will permit your tires to absorb initial impacts more efficiently, transmit the correct secondary impact velocity to the springs and shocks, provide better resistance to cuts and abrasions and increase your traction – especially during braking. At low speeds, due to increased rolling resistance, your steering will feel slower, but at high speeds you will perceive greater steering precision due to better traction. When you are towing or carrying heavy loads, use appropriately higher tire pressures, then air down when empty.

- This suspension system has been designed for installation on vehicles with standard, OE equipment in the engine compartment. If you have added extra or oversized accessory items, mounting the front shocks may be more difficult or, in extreme situations, impossible without modification. If in doubt, please don't hesitate to call us; we will be glad to provide as much assistance as required to fit your system.
- **DO NOT, UNDER ANY CIRCUMSTANCES, DISASSEMBLE YOUR SHOCK ABSORBERS IN ANY WAY. YOUR SHOCKS ARE FILLED WITH OIL AND PURGED OF AIR. OPENING THEM UP ANYWHERE WILL DAMAGE THEM AND VOID YOUR WARRANTY. THEY ARE ALSO FILLED WITH 200 PSI OF NITROGEN AND CAN BE DANGEROUS IF OPENED INCORRECTLY.**
- **KORE INC. recommends this system be installed by a certified technician. In addition to the following instructions, professional knowledge of disassembly/reassembly procedures as well as post installation checks must be known and understood. Attempts to install this system without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Our warranty does not cover abuse or mistreatment of our product during installation, nor does it cover any personal injury, damage to the vehicle or equipment due to improper, careless or slipshod mechanical technique. IF YOU DOUBT YOUR ABILITY TO INSTALL OUR PRODUCT, HAVE SOMEONE QUALIFIED DO IT.**
- Steam cleaning your undercarriage before installation will make the job more pleasurable.
- KORE recommends wearing mechanic's gloves and safety glasses at all times.
- If you bleed your shocks of nitrogen, be sure to refill them with 200 psi. of nitrogen. Do not use less than 200 psi. nor more than 250 psi.

## KORE END LINK INSTRUCTIONS



1. Preserve OE sway bar orientation. Install KORE Billet Drop Blocks above OE anti-sway bar bushings. KORE logo faces outboard. Use stainless socket head cap screws and tighten to 35 ft. lbs.
2. Insert ½" x 3" bolts through lower end link perches.
3. If they do not slide through, drill out perches with ½" bit.
4. Install KORE end link's male rod end on inboard side of lower mount (as shown).
5. Insert bolt with head inboard and nut outboard. Tighten nut to 50 ft. lbs.
6. Install yoke under sway bar (not shown). Use screw driver to hold yoke steady, then install 5/8" washer and nut on top of sway bar flat. Tighten to 70 ft. lbs.
7. Adjust end link so that ¼" of thread is showing.
8. Install end link's female rod end into yoke as shown. Make sure bolt head is on inboard side and nut is on outboard side. Tighten nut to 50 ft. lbs.
9. Repeat procedure on opposite side.
10. Adjust second end link (as in step 8) so that it can be attached to yoke without forcing the bolt through. Don't worry about uneven amounts of thread showing. Every truck is a little different, so your end links will not be vertical, nor will the adjustment be exactly the same. You will obtain the best ride if you follow this procedure exactly.
11. Hold the female rod end steady to retain the end link's orientation, then tighten the jam nut to lock vertical adjustment. Repeat on other side.

KORE INC. warrants the listed products for the listed time period. This warranty does not apply to products which have been improperly applied or installed. The consumer will be responsible for removing from the vehicle and returning any items, shipping prepaid, and for the reinstallation of the part upon return. A copy of the sales receipt is required. KORE INC. will repair or replace at its option, defective products or components. Exclusions from this warranty are the finish, any condition(s) caused by abnormal use or service, and product-specific limitations, if any, listed below.

The loss of use of the product, loss of time, inconvenience, commercial loss or consequential damages are not covered. KORE INC. reserves the right to change the design of any product without assuming any obligation to modify any product already manufactured. This warranty gives you specific legal rights and you may also have other rights which may vary from state to state. There are no warranties, expressed or implied including any implied warranties of merchantability and fitness, which extend beyond this warranty period. There are no warranties that extend beyond the face hereof. Seller disclaims implied warranty of merchantability. This warranty shall not apply to any product sold by KORE INC. which has been modified, customized or improperly installed.

No warranty applies to any part that is designed to be sacrificial and periodically replaced. Examples of these parts are spherical bearings found in shock absorbers, rubber bushings found in control arms, and rod ends found in end links. KORE parts are the finest quality possible. But these are high-performance, race-derived parts and therefore have limited life spans that are, like brake pads and clutch surfaces, dependent upon use and environmental conditions.

#### LIMITED LIFETIME WARRANTY ON PARTS MANUFACTURED BY KORE INC.

KORE INC. warrants any part it manufactures against defects, material, workmanship, or failure of any kind (except for finish or other cosmetic problems) for as long as it is in use on the vehicle for which it was designed, regardless of the owner.

#### LIMITED LIFETIME WARRANTY ON COIL SPRINGS SOLD BY KORE INC.

KORE INC. warrants any coil spring it sells against defects in material, workmanship, including sagging or reduction in static height for as long as it is in use on the vehicle for which it was designed. This does not cover trucks equipped with a snow plow. This warranty applies to the original purchaser and is non-transferable.

#### LIMITED WARRANTY ON SHOCK ABSORBERS SOLD BY KORE INC.

Fox Racing Shox warrants absorbers against factory defects in material and workmanship (except finish) for 12 months regardless of mileage. "Finish" applies to shock shafts damaged by exposure to corrosive chemicals or abrasives. This warranty applies to the original purchaser and is non-transferable. For all Fox shock warranties, call 619-768-1800. For all Bilstein shock warranties, call 858-386-5900.

#### RIGHTS RESERVED

KORE INC. reserves the right to make changes in design, material and specification or to make product changes as deemed necessary without prior notice. Obligations or liabilities will not be assumed with respect to similar products previously advertised.